OneCNC Solid Design



OneCNC Solid Design integrates the Microsoft Windows interface with a powerful CAD engine. Parts can be completely designed and modeled in OneCNC Solid Design, which has been purpose built for mechanical part creation. Industry standard file types such as STEP or IGES or 2D CAD files can be imported from customers files and used as a starting point. OneCNC Solid Design has no CAM functions but the part model and geometry data is in the same file format and can be opened in OneCNC Mill, Lathe, WireEDM or Profiler.

The purpose of this Manual

This manual covers OneCNC Solid Design. The manual provides information on how to get started and use OneCNC, it is not designed as an engineering instruction manual.

Much of the information in this manual is also contained in the OneCNC Help file, which also contains tutorials and reference information about available procedures and commands.

CONTENTS

OneCNC Solid Design	1
OneCNC Environment	. 5
OneCNC Installation	6
Minimum System Requirements	.6
OneCNC Installation	.6
OneCNC Updates	.9
Series 2 Dongle Installation - dongle numbers from 10000	10
Dongle Security	10
Series 1 Dongles - dongle numbers 1 to 9999	11
Start OneCNC and enter the Serial Key	12
Entering serials for optional modules	13
User profile selection	14
OneCNC Network Installation 1	.6
Running OneCNC Dongle Server as a service	21
OneCNC User Interface 2	22
Toolbox	25
Right Sidebar	26
NC Manager	26
Layer Manager	27
Verify	27
History	27
Recent Files list	27
Status Bar	28
Preset Views	28
Construction Plane	29
Display mode	29
Section Tool	30
3D to 2D Automated drawing system	30
Drawing Color and Style selection	30
Modifying Entities	30
Quick Access Toolbar	31
Keyboard Shortcuts	32
Mouse Actions	33

OneCNC Overview	34
2D and 3D Geometry	35
3D Modeling	36
Toolpathing	37
Toolpath management	37
Toolpath Backplot	37
Metal Removal Simulation (OneCNC Mill and OneCNC Lathe only	/) 38
Outputting NC Files	39
OneCNC Integrated Help	40
Help	40
Tutorials	40
OneCNC CAD Tutorial 1	41
Introduction To Cad Drawing	41
Start a new drawing	41
Lines	42
Rectangle	47
Circles	49
Offset entities and boundaries	51
Moving Entities	55
Copy Entities	57
Rotate	59
Setting Current Drawing Properties	61
Trimming Entities	65
Chain Selection	70
OneCNC CAD Tutorial 2	74
2D Drawing	74
Step 1: Draw outer profile	75
Step 2: Draw the angled slot	82
OneCNC CAD Tutorial 3	89
Solid Modeling by Extrusion	89
Step 1: Complete CAD Tutorial 2 and save a copy	89
Step 2: Create a solid by extrusion from curves	90
Step 3: Create the slot with an extrude cut	92
OneCNC CAD Tutorial 4	94
Working With Planes	94
Step 1: Draw a pyramid wireframe	95
Step 2: Position the plane	97
Step 4: Create the truncated pyramid	100
Step 5: Return to default XY plane	102

OneCNC Technical Drawing	103
Automated 3D to 2D Drawing Layouts	103
Add a drawing page with border and title block	104
Add views of the model to a drawing page layout	106
OneCNC Support	109
OneCNC Global Offices	110
Copyright Notice	114

OneCNC Environment

OneCNC has been designed as an integrated manufacturing environment, with purpose built interaction between the CAD and CAM functions.

New users familiar with Windows-based software will be at home with the well organized pull-down menus, toolbox and shortcut keys together with meaningful graphics included throughout the software interface.

The interface is similar to other common Windows-based drawing software and provides compact access to frequently used functions. Users experienced with other mechanical CAD software will appreciate the ability to customize the functionality in a way they are used to using.

CAD functions

The CAD functions are used to draw and create parts. Line, arc, and spline geometry can be combined with NURBS surfaces and solids in a hybrid modeling process. As well as the complete CAD functions for constructing parts from scratch, robust translators are provided for importing parts in other formats. 2D drawing and 3D modeling methods have been designed for ease of use.

CAM functions

The CAM functions are used to create the required NC program toolpaths for CNC machining of your parts. Toolpaths can be edited and reviewed in the NC Manager, which also has functions for backplot, real time preview, and metal removal simulation.

Multiple Views

OneCNC can show single or multiple views of the same object or model. Any view can be dynamically panned, rotated or zoomed. Multiple views make it easier for you to create complex models. While in a command it is possible to select a point in one view and then select the next point from another view.

Multiple Document

You can have more than one part drawing open in OneCNC. This makes it easy to cut and paste from one drawing to another and toggle between drawings. The Recent File tab shows previews of files to help you quickly find the drawing you want. Document management is simple in OneCNC due to the fact that the CAM data is stored in the drawing file.

OneCNC Installation

Minimum System Requirements

Operating System

Microsoft Windows 10, 8, 7, Vista or Windows XP (32 or 64bit) Internet Explorer 7 or later NTFS File System is recommended

Hardware

Minimum 1 GB of quality memory for Windows XP, or 3 GB of quality memory for Windows 8, 7, or Vista, especially if working with complex parts.

Pentium 4 single, dual, or quad core PC. AMD Athlon can be used only if later than 2004 with specs equal to the Pentium 4.

NVIDIA GeForce or similar OpenGL and DirectX graphics card, minimum 1Gb. It is essential you download and install the latest graphics driver for your card, as drivers supplied on install discs may be outdated due to production lead times.

A mouse with 3 or more buttons and a scroll wheel.

One available USB 1.1 or 2.0 port or a suitable parallel port depending on which licensing dongle you have.

CD-ROM drive for installation of standalone version if required. Broadband Internet access is recommended for updating the software.

OneCNC Installation

You will need: OneCNC installer disk or a downloaded update setup file OneCNC dongle CD Key and serial number

There are three steps to installing OneCNC on a single computer: Install the software from disk or an update setup file Plug in the dongle Run OneCNC and enter the serial number to activate it

For network installations, network server software must be installed as well. That process is outlined in the next chapter. All OneCNC products can be installed from the one installer package.

OneCNC 🔫 8	
64bit / 32bit install	
Language	English
Drawing units	Metric
CD key	7000
OneCNC	\otimes

Insert the OneCNC CD or plug in the OneCNC flash drive. Display the drive contents in Windows Explorer and double click 'onecnc_setup.exe'

Language Selection

Select your language from the drop down list.

Units Selection

Select the units you work in, Metric or Imperial (inches). This will set the default drawing units and post-processor configuration units. The units setting can be changed after installation using the Properties dialog on the File menu.

One CNC will open a file drawn in the alternate units at the correct real world size, but the NC toolpaths will be invalid, so you should save the files to separate locations.

CD Key

OneCNC installation requires a CD Key, which is usually found on the inside rear cover of this manual with your serial number, but is sometimes shipped separately from the software for security. Enter the CD Key and click the large 'play' button to start the installation.



The serial number will be requested when you first run the software. Keep a copy of your CD Key and Serial in a safe place as you will need them if you upgrade your computer and need to re-install.



The next dialog advises you to have all other programs closed, which is standard software installation procedure.

😼 OneCNC-XR8 Mill 3D Expert	×
	OneCNC 🔀
Setup will install OneCNC-XR8 Mill 3D Exp	ert in the following folder.
To install into a different folder, click Brows	se, and select another folder.
You can choose not to install OneCNC-XR	18 Mill 3D Expert by clicking Cancel to exit Setup.
Destination Folder	
C:\OneCNC-XR8\Mill 3D Expert	Browse
	< <u>B</u> ack <u>N</u> ext> Cancel

You then have the choice of where to install OneCNC. You can accept the default location or click the Browse button if you want to select your own location. Click Next when you are ready to continue.

In the confirmation dialog you can click Back to review your settings, or click Next to install OneCNC.

If you are upgrading from a previous version of OneCNC, the new installation will be in a new location.

You can still use your existing tool and material libraries, and custom Posts. To do this, copy the Settings folder from your previous installation to your new installation Settings location.

It is good practice to keep a backup copy of your Settings folder.



When all the files have been installed, click Finished to complete the installation. There will be a pause while the dongle driver for Series 1 dongles is installed.

When the installer closes, you are ready to insert the dongle and start $\ensuremath{\mathsf{OneCNC}}$.

OneCNC Updates

Registered users can download updates of the setup file for their version of OneCNC at no extra charge.

Go to http://onecncsupport.com/ and click on OneCNC Updates when you have read the update details. Click on Check For Updates.

Enter your dongle and serial numbers to enter the site. Click on the Register button on the next page to appear. Fill in your registration details, and click Save. Click on the Download button to go to the actual download page.

Select the check box to confirm you have read the update details, and click on the Download button. A dialog will appear asking if you want to Run or Save the file. Select Save and choose the folder on your computer to save the file in. Double click the downloaded file to install the update.

The update can also be accessed by clicking on OneCNC Updates in the Help menu, or the OneCNC Software Updates, Drivers and Posts link in the OneCNC Users Forum.

Dongle Installation

OneCNC requires a dongle for the licensed program to run. A dongle is a small hardware device which verifies your software license.

Series 2 Dongle Installation - dongle numbers from 10000

All OneCNC dongles with a number higher than 10000 are Series 2 dongles.



Series 2 dongles are USB HID devices which look like this. These dongles do not require drivers for a single computer installation.

If you have a network license you will need to install a network dongle driver, as described in the next chapter.

To install a Series 2 dongle

Make sure OneCNC is not loaded or attempting to load. To install the dongle simply plug it into a USB port on your computer. Basically, if the dongle fits, it's the correct port. Do not try to force the hardware or you may damage your computer or dongle.

If you have a timed licence the Windows date and time must be correct before connecting the dongle. It is recommended that the USB port a dongle is plugged into should not be used for other devices.

Dongle Security

Because it is the dongle which verifies your purchase of OneCNC, if a dongle is accidentally damaged or broken the damaged dongle must be returned to OneCNC before a replacement dongle can be issued.

If a dongle is lost or stolen, the replacement price is the full price for the software. Take steps to secure your dongle, and insure it for the replacement cost of the software.

Series 1 Dongles - dongle numbers 1 to 9999

If you have upgraded from an earlier version of OneCNC, you may have a Series 1 dongle with a number less than 10000.



These dongles may be USB or Parallel port dongles, and are now obsolete.

There is no 64 bit driver available for these older dongles, so if you have a series 1 dongle please see your OneCNC dealer for a replacement series 2 dongle.

A series 1 dongle will be replaced at no extra cost with any upgrade to the current version of OneCNC.

Note:

A series 1 dongle will not run the 64bit version of OneCNC.

Until you get your replacement dongle you can install the 32bit version of OneCNC on 64bit Windows by changing the last two digits of the CD Key to 32. For example the CD Key 6432 will install 32bit Mill Express which can be run with a series 1 dongle.

When you change to a new series dongle re-install OneCNC with the standard CD Key.

Start OneCNC and enter the Serial Key

Once installation is complete and the dongle is installed, OneCNC can be started. Double click on the OneCNC shortcut on your desktop, or select the OneCNC shortcut in the OneCNC folder in the Start menu.



The first time OneCNC is started the Licence Manager will look for the dongle. Select 'Single user licence' if you have a standalone installation, and click Continue.



The Licence Manager will open so you can enter the licensed user name and serial number.

Licence Manager			×
Enter your licence de	etails :		
Product :	OneCNC-XR8_64 Bit Mill 3D Expert - Version 62.4		
Client Number :	CN12496	Carl.	
Company Name :			
Email :			
Serial Number :			
Licence Status :	Enter your serial number		
		🗸 ок	X Cancel

The serial is made up of digits 0 to 9 and letters from A to F. The code must be entered exactly as it appears.

When the serial key has been entered the Licence Manager will indicate that the licence is acceptable, and the software can then be started.

Entering serials for optional modules



If you have a serial for an optional module, start OneCNC and click on Register Modules in the OneCNC Help menu.

Enter the serial in the dialog which opens, and the module will be activated.



OneCNC starts with this screen, which gives you the option of selecting the user profile you want to use. The user profile stores all your settings such as toolbar layout, interface color settings and your recent files list.

version	64 bit	
theme	OneCNC	
profile	Default	K
product	Mill 3D Expert	

Clicking on the small arrow opens the user selection dialog, which allows you to select or create settings in the names of specific users for customizing.





Click here to start OneCNC with the selected user profile.

If your user profile or other settings are not being saved, open Windows Explorer and right click on your Settings folder. Select Properties, and clear the "Read-only" check box. Click Apply and click OK to apply the change to all subfolders and files.

OneCNC Network Installation

This step is only necessary for network installations.

For network installations, network server software must be installed on the server or computer the dongle is plugged into.



Series 2 dongles use the OneCNC Dongle Server which is included in the OneCNC installer, and is accessed by a CD Key similar to installing the OneCNC software itself.

To install OneCNC Dongle Server on a computer or server with a Series 2 dongle, you will need:

- OneCNC installer disk or a downloaded update setup file
- OneCNC dongle
- Network CD Key and serial number

OneCNC 🔀		
64bit / 32bit install		
Language	English	•
Drawing units	Metric	-
CD key	60200	
OmeCNC		
Uneche		

Run the installer on the server computer. To install the network dongle server software enter the CD Key 60200.

neCNC Dongle Server
Network installation: - This is the server software and must be installed on the computer that contains the dongle. - You must have a network licence key.
Please enter the serial key : B6BE 5B1F 1ABA 2596 eg 0000-0000-0000-0000
OneCNC Network Server v2.05
Next > Cancel

When the next dialog appears, enter the server software serial. The serial is made up of digits 0 to 9 and letters from A to F. This is not the same as the software serials which are entered later when installing the particular versions of OneCNC such as Mill and Lathe.



The next dialog advises you to have all other programs closed, which is standard software installation procedure.

弱 OneCNC Dongle Server	×
	OneCNC
Setup will install OneCNC Dongle Server in the following folder.	
To install into a different folder, click Browse, and select another folder.	
You can choose not to install OneCNC Dongle Server by clicking Cano	el to exit Setup.
□ Destination Folder	
C:\OneCNC Server	Browse
OneCNC Installation	> Cancel

You then have the choice of where to install the server software, the default installation is as shown.



The next dialog indicates you will need to unblock the firewall for this application only. Click Finish to complete the installation.



Here is the Windows Firewall dialog where you have to click Unblock for the dongle server software to work. This has no effect on network or internet security, it is only allowing any PC on the local network to access the OneCNC Dongle Server. The server software is now installed and working.



There will now be an icon in the Taskbar at the bottom of your screen, indicating the dongle server software is running.

You can click the icon to open the Dongle Server interface, but it is not necessary to have the Dongle Server interface open for client computers to access the dongle.

OneCNC Dongle Server 2.05	-		×
Users connected : 0			
- User #2, IP:192.168.0.2, MAC:00-04-61-4C-05-5D, *connected * 0 Waiting connections			
Status :		Max use	rs : 10
Refresh Serial		Hide	:

The interface allows you to see how many clients are connected to the Dongle Server. You will not see a connection as shown here, until the OneCNC programs are installed on the client computers.

To install OneCNC on the client computers, start the OneCNC installer on each computer, and load the OneCNC application using the CD key for OneCNC.

Running OneCNC Dongle Server automatically

You can run OneCNC Dongle Server automatically so you do not have to start it if the server has been shut down.

Setting up a scheduled task will install OneCNC Dongle Server as a service which will automatically restart when the network server is started.

Firstly, install OneCNC Dongle Server as shown in the previous section. You can then use the Windows task scheduler to set up an action to start the OneCNC Dongle Server when the computer is started. You must be logged on as an administrator to perform these steps.

To open the Windows Task Scheduler, open Control Panel, click on System and Security, and click on Administrative Tools (if Control Panel opens in Classic view you can just double click on Administrative Tools). Double click on Task Scheduler.

In Windows Server, open the Server Manager and navigate to Server Manager > Configuration > Task Scheduler .

Task Scheduler		- 🗆 X
File Action View Help		
Task Scheduler (Local)	Task Scheduler Summary (Last refreshed: 6/12/2019 2:21:37 PM)	Actions
Isk Scheduler Library Microsoft	Ourse insure of Tests Selected at	Task Scheduler (Local)
	Verview of lask Scheduler to create and Wou can use Task Scheduler to create and mage common task that your computer will carry out automatically at the times you specify. To begin, click a command in the Action menu. Task status are stored in folders in the Task Status of tasks that have s Status of tasks that have s Status of tasks that have s Summare 0. table - 0 supports accorded 0 stored	Connect to Another Computer Create Basic Task Create Task Import Task Display All Running Tasks Enable All Tasks History AT Service Account Configurati View Q Refesh
	Task Name Run Result Rur Last refreshed at 6/12/2019 2:21:37 PM Refresh	P Help

Click Create Basic Task. Enter the name and description for the task, and then click Next. Select When the computer starts, and click Next. Select Start a program, and click Next. Click Browse to find the OneCNC server program, which will typically be at C:\OneCNC Server\onecnc_server.exe Click Next when you have selected the program. Review the settings you have made and click Finish.

Restart the server to apply the changes you have made.

OneCNC User Interface



The OneCNC user interface has been carefully designed for ease of use.

<u>File</u> <u>Edit</u> <u>View</u> <u>N</u>C <u>Window</u> <u>Help</u>

Windows menus give you access to many features in OneCNC. Menu items with a pointer on the right side automatically open sub-menus which you can slide the mouse across to select from.



The Mill Expert interface is shown in this chapter. The available modeling and CAM functions you see will vary for different types or levels of OneCNC. OneCNC Solid Creator is intended for design only and has no CAM functions.

Drawing Window



The file you are working on is displayed in the drawing window, which is a real-time OpenGL model view. This allows you to view your object by means of dynamic rotation, panning and zooming.



Multiple Views of the same file can be shown. When parts become complex it can be useful to view and edit one object from various angles simultaneously. This function can be accessed from Window > Window Layout.

Multi Document



You can have more than one file open in OneCNC. When the file windows are maximized you will only see one file at a time. You can select the file to display from the Window menu.



Clicking the Restore Window button will display each file in its own window.



The file windows can be controlled by dragging, or using the Cascade and Tile commands on the Window menu.

Toolbox

The Toolbox is a menu system which is shown in the left sidebar.



When	you	start	OneCNC	you	will	see	the	toolb	ox
Home	mer	าน.							

The Home menu icons are grouped into commands for drawing, modeling, and CAM functions.

The toolpath functions available will vary with the version and level of OneCNC you are using.

Com	mand Manager
	•
•	Point
/	Point at arc center
•	Points on chain
Ъ	* 🕆 ። 💿 🔗
×	coordinate
•	World : On plane :
	X-Coord 0
×,	Y-Coord 0
٠	Z-Coord 0
	🗹 ok 🛛 + İnc

Each icon in the toolbox Home menu will open a sub-menu from which you can select a specific command.

For many commands entry boxes will appear where you can input required values.

Click on the Home icon at the top of the Toolbox to return to the Home menu.

Clicking on the dotted button at the left of the toolbox will hide it.

Click on the button again to bring the toolbox back into view.

On the right of the screen the right sidebar has panels for:

- NC manager
- Layers Manager
- CAD Verify
- History
- Recent file list



Clicking on the dotted button at the right of the sidebar will hide it.

Click on the button again to bring the sidebar back into view.

NC Manager

•

The NC Manager displays the toolpaths you have defined.

Machining operations can be grouped, and operations can be renamed, edited, rearranged or duplicated.

NC Manager				
3				
mill express pocket				
- Express_1 Default post				
1:Mill Pocket on				
2:Mill Profile	on			
🚽 3:Rectangular groove	on			
🚽 4:Circular Groove	on			
S:Large Hole	on			
🍾 6:Simple Hole, 10mm	bolt, Z0 to Z-25 on			
20 MM CARBIDE END MILL				
Tool diameter	20 mm			
Tool tip radius	0 mm			
Material top	ZO			
Max cut depth	25.5 mm			
Final Z clearance	5 🖌 🗙			
Rapid clearance	5 3			
Station number	2			
Length offset	2			
Diameter offset	2			
Spindle Speed	4392			
Coolant No.1				
Work offset G54				
Feedrate	773			
Plunge feedrate	386			

Layer Manager

When you draw an entity it's created on the currently selected layer. The Layer Manager is used to create, name or delete drawing layers.

The panel shows a list of layers in a drawing. You can turn off a layer by closing the eye for that layer in the Layer Manager. Entities on the layer are still in the drawing but will not be visible.

Verify

The Verify panel holds tools to read data from geometry.

You can find exact values for position length or area for 2D entities, and volume of 3D solids. You can also find the angle and distance between entities.

History

As you construct your part, a record of commands used is created in the History tab.

You can roll construction back or forward like a multiple undo and redo. If you roll-back your history and start new construction, the rolled back construction is replaced with the new construction.

•? <td

History			
Start			
Line			
Circle			
Circle			
Fillet			
Fillet			
Scissors			
Scissors			
Layers	Verify	History	Recent



When you save a file, a thumbnail image of it is added to the Recent file list.

The list shows if a file is open, active or closed.

You can open a closed file by clicking on the thumbnail image.





Verify

Status Bar



The Status Bar at the bottom of the OneCNC window provides you with functions related to the appearance of objects, and a message panel which shows prompts to help you use the program.

Preset Views

OneCNC has a set of preset views so you can select the direction you want to look at your model from.



Click on the View icon to open the preset view selector.



Construction Plane

When you draw or model in OneCNC you can use a coordinate system which is independent of the world XYZ coordinate system. OneCNC displays the Construction Plane which is a visual reference for the XY plane of the current construction coordinate system.

The Construction Plane is controlled using the Plane dialog, which is opened by the Plane icon in the Status Bar.

The Working With Planes tutorial in this manual covers the use of Construction Planes.

Display mode

Display controls the appearance of 3D surfaces and solids.



Click on the Display icon to open the Display mode selector.



Click on the icon for the display mode you would like to change to.

If you are extracting 2D profiles from 3D objects it can be useful to use the Transparent or Wireframe modes to access obscured parts of the model.

If you set the display mode to Wireframe, be sure to return it to another mode before attempting any modeling commands as you will not see any surfaces or solids.

Section Tool



The Section tool is used to view a cross-section of your work parallel to the current working plane. It can also be used to create section geometry.

3D to 2D Automated drawing system



In Expert versions of OneCNC and OneCNC Solid Creator you will see the Pages icon which opens the automated 3D model to 2D CAD drawing system. This can be added as an optional module to OneCNC Professional versions.

Drawing Color and Style selection



OneCNC has a 2 color drawing system. Color selection boxes in the Status Bar set the color for new entities. The color selection box on the left is for geometry and that on the right is for surfaces and models.



To select the line style and line thickness for new geometry entities click the Styles icon.

Modifying Entities



Click Modify to change the color, line thickness, line style or layer of existing entities.

Modify Selected A	ttributes		×
Attributes	Color : Thickness : Style : 	Layer : Model Geometry Model STOCK	
		🗸 ОК	🗙 Cancel

Select the check boxes for the attributes you want to change and select the new values.



The Quick Access toolbar is a custom toolbar you can use to display icons for commands you use often.



When you install OneCNC the Quick Access toolbar will be empty except for the Quick Access icon. Click on the Quick Access icon to open the Quick Access customization dialog.

ommands :		Quick access commands :	
Rotate around line	^	Line : Line	
Blank selection		Arc : Circle	
Undo		Edit : Scissors	
Redo	>>	Verify : Verify single	
Move from plane	6		
Move to plane			
Project entities	_		
Verify			
Verify single			
Verify 2 entities			
Verify circle			
Verify solid			
Tape measure			
Area of surface			
Verify end point			
Splines			
Spiral			
Optimize lines			
Cardinal spline			
B-Spline			
Bezier spline			
Text			
Tevt	•		

Select the command you want to add in the Commands list on the left of the dialog. A keyboard shortcut can be assigned to the command in the 'Assign hot key' entry box.

You can right click on an icon you use regularly to add it to the Quick Access toolbar.



Keyboard Shortcuts

OneCNC provides a default set of keyboard shortcuts, which are a powerful way of accessing functions quickly by pressing a key or combination of keys. You can add your own keyboard shortcuts in the 'Assign hot key' entry box of the Quick Access dialog.

The following lists give the default shortcut key settings in OneCNC.

View shortcuts

Arrow Keys	Rotate model horizontally and vertically
Arrow Keys + Shift	90 Deg steps rotate right left up down
Ctrl + Arrow Keys	Pan
Space Bar	Preset View selection dialog
Space Bar double press	CAD View
Delete	Delete selected entities
F	Zoom to fit
Z + Shift	Zoom in
Z	Zoom out
W	Zoom to a window
Ctrl + 1	Top View
Ctrl + 2	Bottom View
Ctrl + 3	Left View
Ctrl + 4	Right View
Ctrl + 5	Front View
Ctrl + 6	Back View
Ctrl + 7	Isometric View
Ctrl + 8	Trimetric View
Ctrl + 9	Dimetric View
Ctrl + 0	Default View

Drawing shortcuts

Р	Point
L	Line
R	Rectangle
0	Offset
Н	Hatch
С	Circle with given radius
Ctrl + F	Fillet Arc

File shortcuts

Ctrl + N	New file
Ctrl + O	Open file
Ctrl + S	Save file
Ctrl + Tab	View next open file
Ctrl + P	Print

Edit and modify shortcuts

S	Select Single
L	Select nearest line when in Single Select
mode	
A	Select nearest arc when in Single Select
mode	
Ctrl + A	Select All
Ctrl + Z	Undo
Ctrl + Y	Redo
Ctrl + X	Cut to clipboard
Ctrl + C	Copy to clipboard
Ctrl + V	Paste from clipboard
Ctrl + D	Delete
Μ	Move
В	Blank selection
Т	Trim One
Ctrl + T	Trim Two



Mouse Actions

Left Button Right Button Mouse Wheel Middle Button + Ctrl Middle Button Middle Button + Shift Enter / Select Escape / End Function Zoom to/from cursor Pan Rotate view Zoom

OneCNC Overview

The purpose of OneCNC is to create NC code programs for CNC machines. The workflows for the various types of OneCNC are as follows:

OneCNC Mill or Mill with Multi-axis module

- 1. Draw or import part geometry or model
- 2. Define toolpaths to cut the part
- 3. Preview or simulate to verify toolpaths
- 4. Output NC program to send to the machine

OneCNC Lathe

- 1. Draw or import part geometry or model
- 2. Define toolpaths to turn the part
- 3. Preview or simulate to verify toolpaths
- 4. Output NC program to send to the machine

OneCNC Lathe with Mill-Turn module

- 1. Draw or import part geometry or model
- 2. Define turning and live tooling toolpaths
- 3. Preview or simulate to verify toolpaths
- 4. Output NC program to send to the machine

OneCNC WireEDM

- 1. Draw or import part geometry or model
- 2. Define wirepaths to cut the part
- 3. Preview to verify wirepaths
- 4. Output NC program to send to the machine

OneCNC Profiler (Nesting for plasma, laser, waterjet or router)

- 1. Draw or import part geometry
- 2. Add part shapes to the Parts list
- 3. Nest parts to sheets
- 4. Define drill, engrave and cutting operations for the nested sheets
- 5. Preview to verify toolpaths
- 6. Output NC programs to send to the machine

2D and 3D Geometry



Geometry drawing

OneCNC parts are constructed using pure geometry. Boundaries can consist of lines, arcs or splines constructed in 3D space.

Layers

The Layer Manager sidebar panel is used to create, select, open and close layers which are used to organize your drawing.

Dimensions and Text

All 2D and 3D geometry can be dimensioned and annotated. Text labels can be added to parts and converted to geometry for engraving.

Drawing Layout Patterns

Borders, title and revision blocks, and bill of material lists can be saved as patterns and loaded into drawings as required.

3D to 2D Technical Drawing System

Expert versions of OneCNC include the 3D to 2D drawing system which automates the preparation of 2D drawings for printing. 2D technical drawings are created as page layouts in your ONECNC file, using title block and border templates. 2D views of the 3D part model can be created automatically and added to a technical drawing. The system can be added to Professional versions of OneCNC as an optional module.

3D Modeling



Available in OneCNC Expert and Professional versions

Surfaces Creation

Planar and curved surfaces can be constructed using the many available strategies.

Solids Creation

Solids creation from Primitives allows you to create basic shapes such as Cubes, Spheres, and Cylinders. Solids can also be created by revolving or extruding geometry.

Hybrid Solids Creation

In the hybrid modeling technique a closed set of surfaces can be unioned to become a new solid. Existing solids can be merged with a closed set of surfaces to become a new solid.

Model Operations

New solids can be created by the cutting, uniting or intersection of existing solids. Solids can be split by a plane, or broken into separate surfaces.

Expert Tools

Expert versions of OneCNC have additional advanced modeling tools.
Toolpathing

In all versions of OneCNC except Solid Creator, toolpaths can be defined by clicking an icon in a Toolpaths menu in the Toolbox and completing any selection or settings entries that the toolpath requires.

Toolpath management

When you define a toolpath it will be added to the active toolpath group in the NC Manager.

An NC file can be output from a single operation, all the operations in a single group, or all operations in all groups in the NC Manager.

Right clicking on a group or toolpath will open a context menu with commands for frequently used functions such as preview and backplotting.

In Mill or Lathe the lower section of the NC Manager displays settings for the currently selected toolpath which can be edited.

NC Manager				
3				
mill express pocket				
- Express_1 Default post				
1:Mill Pocket		on		
2:Mill Profile		on		
🚽 3:Rectangular groove		on		
🚽 4:Circular Groove		on		
Ø 5:Large Hole		on		
🍾 6:Simple Hole, 10mm	bolt, Z0 to	Z-25 on		
20 MM CARBIDE END MILL				
Tool diameter	20 mm			
Tool tip radius	0 mm			
Material top Z0				
Max cut depth	25.5 mm			
Final Z clearance	5	XX		
Rapid clearance	5	5		
Station number	2			
Length offset	2			
Diameter offset	2			
Spindle Speed	4392			
Coolant	No.1			
Work offset	G54			
Feedrate	773			
Plunge feedrate	386			



Toolpaths can be backplotted, which means they are drawn as geometry on a special layer named Backplot. Feed moves are drawn in green, and rapid moves in orange. Reposition moves in highspeed machining are drawn in blue.

Toolpath Backplot

Toolpath Preview



The Live Preview window shows an animated preview of the toolpath, backplotting as it goes. In Mill or Lathe the cutting tool will be shown traveling along the toolpath.

Metal Removal Simulation (OneCNC Mill and OneCNC Lathe only)



In all levels of Mill and Lathe, OneCNC provides real-time toolpath metal removal simulation. By simulating the feed and speed of the process, you can check the machining operation prior to sending to the CNC machine.

OneCNC Mill also provides Rest Material Verification, which highlights the thickness of material left on the part until it is fully machined.

NC Proces	ssing				×
Process	Toolpath Group	Multiple Parts			
	Simulate / Rest	Post	Default	 ✓ Setup 	
	Post				
	Job Sheet	Status	:		
	Backplot				
	_	Description	Express_1		
	Preview	Program Number	4532		
•••	Quick Check	Part Number	P000034		
		Author	OneCNC		
		Workshift	X0.000, Y0.000, Z0.000	Set	
		Table Load Move	None	Set	
		Notes	Express Demonstration Part	^	
				~	
			Renumber operations		
		1			
			~	OK X Cance	el

Clicking the Process icon in the NC Manager opens the NC Processing dialog. You can enter notes or a program number before the file is output. OneCNC formats the NC file using a machine specific definition called a 'Post'. OneCNC is supplied with Posts for all popular machines, and it is easy to create a custom Post by copying and editing an existing format.



Editing and sending the created program

When you output the NC file for your job it will open in OneCNC Link, the complete editor and DNC transfer program, where you can see your NC code before the final stage of sending the completed NC program to the CNC machine.

OneCNC Integrated Help

At OneCNC we put a lot of effort into making OneCNC the world's easiest CAD/CAM package to use. OneCNC has several features within the program to help new users quickly adapt to its powerful but easy to use features.

Help



If there is a specific part of the program you want to learn about, click on Contents in the Help menu.

The help files will open in a new window, with navigation controls at the top. The Back or Forward buttons allow navigation between help files you have visited, like an internet browser. The Home button will return you to the first page shown on the screen.

Tutorials



Clicking on Tutorial in the Help menu will take you straight to the OneCNC Tutorials folder in the Help files.

There are step by step tutorials for 2D CAD, 3D modeling, and how to define machining toolpaths for each version of OneCNC.

Context Sensitive Help

OneCNC uses Context Sensitive help. This means if you are using a function and need help on it, press F1 and OneCNC Help will open showing the relevant topic.

OneCNC CAD Tutorial 1 Introduction To Cad Drawing

This Tutorial is designed for all OneCNC products.

This tutorial will quickly take you through the essential functions for drawing and modifying geometry in OneCNC, to get you up to speed in the shortest possible time. In the exercises in this chapter, exact positioning is not important. The aim is to get an overall view of the process of drawing in OneCNC.

Start a new drawing

When you start OneCNC you will have a new file ready to draw in.



You can also start a new file by clicking on the New File icon in the Standard toolbar.

The first thing you should do when starting work in a new file is to click Save and save the .ONECNC file. If you save this tutorial you will be able to open it and resume where you left off if you are interrupted.



It is good practice to save your file regularly as you work. When working on complex parts, you can use the Save As command on the File menu to make incremental copies of your work, saving as "file_01.ONECNC", "file_02.ONECNC", and so on.

It is strongly recommended that you save a backup of all your work in another location once a day, and in an offsite location every week.



The part will open in the default 3D view. The darker rectangle is the construction Plane, which indicates the XY plane of the coordinate system you will be drawing in. Later you will see how you can move and rotate the Plane to define a new coordinate system but for now we will leave it in the default XY position.

Lines

We will start with lines, the most common drawing entity.



Click on the Line icon to open the Line menu in the toolbox.



The Line icon in the Line menu is highlighted, showing that the Line command is started automatically.

When the Line command is active, coordinate entry boxes will be available in the toolbox. Coordinate entry can be used for the first or second point of any line segment.

You can enter coordinates for a position in the World coordinate system, or the coordinate system of the current plane.

The current mouse pointer position is displayed in the toolbox, so you can also use it to check the position for a grid snap.



The mouse pointer will snap to grid positions in the drawing plane. Click to select a start point for the new line.



The mouse pointer will have a preview of the line to be drawn attached to it. Click on a new grid point to draw a horizontal line.



The Line command draws consecutive lines. Click again to draw a vertical line from the last point.



Move the mouse pointer horizontally again and you will see an indicator line when the new line endpoint is aligned with the start position. Click to end the line on the vertical alignment.



Hold the mouse pointer near the start of the chain of lines and you will see the Endpoint indicator. Click to end the new line on the first line endpoint.



Hold the mouse pointer near the previous line and you will see the Midpoint indicator. Click to end the new line on the previous line midpoint.



Right click to end the chain of lines.

The Line command will still be active. You can start a line at a new position and continue as before.



Click near a line you have already drawn. The start point will be on the existing line.

coordinate						
	World :	On plane :				
X-Coord	10	10				
Y-Coord	20	20				
Z-Coord	0	0				
	🖉 ok	+ Inc				
parameters						
Line Length 0						
Line Angle 0						
adjust along position						
Dist	Distance along 15					
	Ratio along	0.3				

The toolbox will display the distance the new start point is along the existing line.

Change the value in the Distance along entry box to move the start point to a new position along the base line.

If you prefer you can enter the position on the base line as a ratio of the base line length.

The Distance along and Ratio along values are interactive.



Move the mouse pointer near another line and click to connect to it.



Right click twice to end the Line command.







Start the Line command again and practice drawing lines. You can enter an exact position for a line endpoint by entering coordinates in the toolbox. You can also define a line by entering a value for line length, or angle from the last line segment.

Delete the lines when you are ready to continue.

Rectangle

The Rectangle command creates a rectangle with the option of a given radius fillet on all the corners.



Click on the Rectangle icon in the Line menu to start the Rectangle command.





To define the first corner of the rectangle you can click on an entity or grid snap, or enter coordinates in the Toolbox.

This will be the point where the sides of the rectangle intersect before they are filleted.



A preview of the rectangle is shown, with the second corner attached to the mouse pointer. Click on or enter a position for the second corner. The second corner can also be set by entering an X length and Y width for the rectangle.



The mouse pointer is still active, ready to select a start corner for a new rectangle.

Draw some more rectangles, using different options such as a zero Corner Radius, or using values for Length or Width.

P

Right click when you are ready to end the command.



Click on the Select All icon to select the rectangles you have just drawn.



Click the Delete icon to clear the drawing area.

Circles

The Circle command creates a Circle with a given diameter.



Click on the Arc icon to open the Arc menu in the toolbox.

• Circle	
----------	--

The Circle icon in the Arc menu is highlighted, showing that the Circle command is started automatically.

coordinate			
	World :	On plane :	
X-Coord	0	0	
Y-Coord	0	0	
Z-Coord	0	0	
	🗹 ok	+ Inc	
parameters			
	Diamete	r 35	Enter a Diameter for the circle in the Toolbox



A preview of the circle is attached to the mouse pointer.

Click on or enter a position for the center of the circle.



The Circle command continues and you can place another circle by its center point.



You can change the Diameter in the Toolbox before placing the next circle.





Right click when you want to end the Circle command.



Click Select All and then click the Delete icon to clear the drawing area.

Offset entities and boundaries

An offset entity or boundary is often needed when drawing a part. In OneCNC this is done using the Parallel/Offset command.



To practice the Parallel/Offset command, draw a rectangle with filleted corners.

Offsetting single entities



Click on the Parallel/Offset icon in the Line menu to start the command.



When the command is started, enter the distance you want to offset in the Offset Amount entry field in the Toolbox.



Select a side of the rectangle.



Move the mouse pointer around, and you will see a preview of the selected entity being offset. When the preview is where you want the offset, click to create the offset entity.



You can now select another single entity, and create an offset by clicking when the preview is where you want the offset.





Right click to end the command when you have finished making single offsets.

Offsetting a boundary



Delete the single offsets you made, or click on Undo till you return to the rectangle with filleted corners.



Click on the Parallel/Offset icon in the Line menu to start the command.



Enter the distance you want to offset in the Offset Amount entry field in the Toolbox.



Select the same side of the rectangle. The single offset preview will appear, but do not click to place it.



Move the mouse pointer near the end of the selected line, and the connected boundary will be highlighted. Click to select the boundary for offsetting.



Now the preview will show a preview of the entire boundary being offset. Click to place the offset. The command will recur.



Right click when you have finished creating offsets.



Select All and Delete before continuing.

Moving Entities

Entities can be moved, copied, scaled, rotated and mirrored. These Transform functions can be accessed by clicking on the Transform icon in the Toolbox to open the Transform menu.



We will start with the Move command. Use grid snaps to draw a square evenly spaced around the world origin, and draw two circles on the corners at the left of the square.



Before starting a Transform command, entities must be selected. Click on the Select icon to select entities one at a time.



Click on each of the circles to select them. Selected entities change color to red when they are selected. If you select an entity by mistake, click on it again and it will be removed from the selection set.





Click on the Transform icon to open the Transform menu in the toolbox.



The Move icon in the Transform menu is highlighted, showing that the Move command is started automatically.



You can select or enter a position as the start point for a move. Click on the midpoint of the line between the circles.



A preview of the entities being moved will be attached to the mouse pointer. Shadows indicate the original position of the entities. Click on the midpoint of the opposite line to move the circles.

Right click to end the Move command. The moved entities are still selected, ready for another command.





Click Deselect All to leave the circles unselected.

Copy Entities



Click on the Select icon, and select the circle at the top of the square.



Right click to end the selection.



 \mbox{Click} on the Copy Move icon in the Transform menu of the toolbox to start the Copy command.



Select the intersection of the circle and the right side of the square as the start point of the move.



Move the mouse pointer to the left side of the square. Click on the intersection of the left side of the square and the dashed horizontal indicator to set the finish point of the move.

Right click to end copying from the current start point.



The Copy move command is still active. Select the center of the circle as the start point for another copy.



Click on the diagonally opposite corner of the square to create a copy there.



Right click to end the current copy.



Right click again to end the Copy move command.



Click Deselect All to leave the original circle unselected.

Rotate

Entities can be rotated about a selected center of rotation. The axis of rotation can be parallel to the X, Y, or Z axis of the World or Plane coordinate system.



Select all the sides of the square.



Motate

Click on the Rotate icon in the Transform menu.



To select the center of rotation, move the mouse pointer to the intersection of the X axis and Y axis. Click when the square World origin indicator appears.

parameters	Т
# Copies 📝 🚺	С
Scale 📃 1	Т
Attributes 📃	
Rotation Z plane 0	
Rotation X plane 0	
Rotation Y plane 0	
Rotation Z 0	
Rotation X 0	
Rotation Y 0	

To create the rotated square as a copy of the briginal, enter 1 for the #Copies value in the Toolbox.

The toolbox now shows six options for the axis of rotation. The default rotation mode is Rotation Z plane, which rotates entities in the current drawing plane.

You can enter the exact degrees of rotation in any of these fields, but for common rotation amounts a rotation protractor with markers at 15° intervals is shown in the drawing window.



Move the mouse pointer around the protractor, and click to rotate the square by 45°.



Right click twice to end the rotation command.



Click Deselect All to leave the original square unselected.

Setting Current Drawing Properties

OneCNC has a 2 color drawing system, controlled by color selection boxes in the Status Bar.



The color selector on the left is for geometry and that on the right is for surfaces and models. To set the current color, click the selector and select the color you want to use. To switch back to the default color just click the small square in the corner of the selector.

	н		
L	н		
	I		
	н	-	

To select the line style and line thickness you would like all new entities to be drawn with, click the Styles icon.

OneCNC uses red to indicate an object is selected, so don't use red for drawing.

Using Layers

Every entity created in OneCNC is said to be 'on' a Layer. Layers give you control over entities on each layer as a group. For example, if you draw dimensions on a layer named 'Dimensions', you can then turn off display of the layer to hide all dimensions while working on the drawing geometry.

Click on the Layer tab at the lower right of the screen to open the Layer Manager.

Layers	J			÷	R
	Layer1				
Layers	Verify	History	Recent		

Up till now you have been working in a new file, on the default layer, Layer 1. We will now create a new layer and move some of the geometry to the new layer.

Layers			
🍳	,		₽ _₽
9	Layer1		Add a new laver
			Add a flew layer
Layers	Verify	History	Recent

To add a new layer, click on the + icon at the top of the Layer Manager.

Layers	Layer1 Layer2		Rename the layer
Layers	Verify	History	Recent

The new layer is created with the default name Layer 2. Click on the icon next to the + icon to rename the layer.

Enter Name		x
Circles		
	🗸 ок	🗙 Cancel

Enter 'Circles' as the name for the new layer, and click OK.

Layers	ļ			4.⊼
× 9	Circles Layer1			
Layers	Verify	History	Recent	

The Layer list is sorted alphabetically, so the Circles layer is now above Layer 1. It is highlighted in blue, indicating it is the active layer new entities will be created on, but the X in the visibility column shows it is an empty layer.



Select all the circles in your practice drawing.



Click on the Modify icon in the Status Bar.

Default Layers

You can set default layers to be contained in each new drawing from the File menu > Properties dialog. Select the Layers tab, click New, give the layer a name, and set a default color, line type, and width.

Modify Selected A	ttributes			×
Attributes Color Thickness Style Layer	Color : Thickness : Style : Style :	Layer : Circles Circles Circles Layer1	R	
			🗸 ОК	🗙 Cancel

In the Modify Selected Attributes dialog, you can change the color, line type, thickness, or layer of entities. Select the Circles layer in the Layer list to move the selected entities to that layer.

Layers	J			÷	N
99	Circles				
Layers	Verify	History	Recent		

There is now a green eye icon in the Circles layer visibility column, indicating all entities on the layer are visible. The red selection square indicates all entities on the layer are selected. Click on the square to deselect the circles.

Layers	,			÷	2
	Circles Layer1				
Layers	Verify	History	Recent		

Click on the open eye icon for the Circles layer and it will close. This will turn off display of all entities on the layer.



Now you will be able to see the squares clearly.

Trimming Entities

Trim functions are used to shorten or extend existing entities.

Scissors

The quickest way to trim away unwanted parts of geometry is to use the Scissors tool.



Click on the Trim/Break icon in the Toolbox to open the Trim/Break menu.



Click on the Scissors icon to start the Scissors command.



Click on an unwanted part of a line or arc.



The geometry will be trimmed back to the next intersection with another line or arc, and the command continues. You can continue trimming by clicking on unwanted parts of geometry.



Right click to end the command when you have finished trimming entities.



The Scissors command cuts entities back to the next intersection or endpoint in each direction from the point where you clicked on the entity. If you click on an entity which is not crossed by another line or arc, it will be deleted.

Trim Two

This function will shorten or extend two arcs or lines to their common intersection. It is an important function as it can be used to make sure a chain of entities are properly connected at their endpoints.



Open a new file to practice using the Trim Two command. Draw some lines that cross, and some unconnected lines.



Start the Trim Two command by clicking the Trim Two icon in the Trim menu of the Toolbox.



Click on the first line you want to trim, on the side of the intersection that you want to keep.



Click on the second line you want to trim, on the side of the intersection that you want to keep.



The lines will be trimmed to their intersection. In this example both lines were shortened.

The command continues, and you can click on the next line you want to



trim.



Click on the next line to trim. In this example one line will be shortened and one will be extended to meet at their intersection.





Right click to end the command when you have finished trimming. The four lines in this example have now been trimmed to form a closed boundary.



Click Select All and then click the Delete icon to clear the drawing area.

Some CAM operations require selection of consecutive entities as a profile chain.

Trim Two ensures that the junction between two entities is properly trimmed for chain selection, and can be used to repair a chain that will not select properly.

Chain Selection

Chain selection is an important function that selects consecutive entities to form a profile chain. A profile chain can be open or closed. For many CAM functions you will need to select a profile chain of consecutive entities as the first step of the toolpath definition.



To practice chain selection, draw a filleted rectangle.

Selecting a complete profile as a chain

Click on the Chain Selection icon to enter chain selection mode.



The mouse pointer changes to the word 'start'. Click on the entity that will be the first in the chain.



Move the mouse pointer around till the red arrows are pointing in the direction that you want to chain select. Click to set the direction.



The mouse pointer changes to the word 'end'. Click on the last entity of the chain you want to select, or press the F3 key to select all consecutive entities automatically.



The chain will be selected. You can now start to select another chain, or right click to end chain selection.

Selecting part of a profile as a chain



Click on the Deselect All icon to clear the previous selection.



Click on the Chain Selection icon to enter chain selection mode.



The mouse pointer changes to the word 'start'. Click on the entity that will be the first in the chain.



Move the mouse pointer around till the red arrows are pointing in the direction that you want to chain select. Click to set the direction.


The mouse pointer changes to the word `end'. Click on an entity to end the chain.



The mouse pointer is still seeking a chain end. You can click further along the chain to add one or more entities to the chain selection.



Right click when you are ready to finish selecting the chain. You can now start to select another chain, or right click again to end chain selection.

OneCNC CAD Tutorial 2 2D Drawing

This Tutorial is designed for all OneCNC products.



In this tutorial we will be using some of the time saving features of OneCNC CAD drawing to show how easily a part can be constructed. We will be drawing a part with fillets and chamfers, and a slot at an angle of 75 degrees.

Start a new file, and save it as 'Cad Tutorial 2'.



Click on the View icon in the Status Bar to open the View menu, and select CAD View.

CAD view is a special top down view, specifically for 2D drawing in the



XY plane.

While in CAD view all drawing is in World coordinates.



Click on the Rectangle icon in the Line menu to start the Rectangle command.

Enter 0 for Corner Radius, to draw the rectangle with sharp corners.



Enter coordinates in the toolbox or use a grid snap to start the rectangle at X10 Y10. You can then enter 150 for Length and 100 for Height to make the rectangle 150 wide in X and 100 high in Y.

To create the semi-circle on the right side of the part, start the Arc



Sketch command on the Arc menu.

Click on the midpoint of the vertical line at the right side of the part to



locate the center of the arc.

The Arc Sketch function now requires the arc Radius, Start Angle, and End Angle. Each of these can be defined by entering a value in the toolbox, or clicking on an entity or grid snap.

coordinate		
	World :	On plane :
X-Coord	175	175
Y-Coord	60	60
Z-Coord	0	0
	🗹 ok	
parameters		
	Radius	15
	Start Angle	0
	End Angle	0





Click on the endpoint above the arc center to set the Start Angle to 90°.



Click on the endpoint below the arc center to set the End Angle to 270°.



/ Line L

To draw the angled line at the top left of the part, select the Line menu to start the Line command.



Click on the vertical line at the left of the part, between the midpoint and upper end.

parameters	
Line Le	ength 0
Line /	Angle -90
adjust along positi	on
adjust along positi Distance a	on along 40]

To fix the start point of the line at 40mm from the end of the selected line, enter 40 as the Distance along value in the toolbox.



Enter -60 for the Line Angle.

This will fix the angle of the new line at 60° from the direction of the anchor line.



Move the mouse pointer along the new line preview until it locks onto the horizontal line at the top of the part, and click to draw the line.



We can now trim away the unwanted line segments.



Start the Scissors command on the Trim/Break menu.



Click on the segment within the semicircle to remove it.



Click on the segments at the top left of the part to remove them.



Right click to end the Scissors command.

Next we will create the fillet on the lower left corner of the part.



Start the Fillet command on the Arc menu.



Next we will create the chamfer on the lower right corner of the part.



Start the Chamfer command on the Line menu.



Step 2: Draw the angled slot

The first step in construction of the slot will be to draw the centerline.

Select the Line menu to start the Line command.



Move the mouse pointer near the center of the fillet arc, and click to place the start point of the line there.

parameters	-
Line Length 25	
Line Angle 0	
adjust along position	
dajaat along position	
Distance along 0	

Type 25 in the Line Length box, and press Enter.

parameters	
Line Length	25
Line Angle	45]
adjust along position	
adjust along position	
Distance along	0

Type 45 in the Line Angle box and press Enter again.

The line will be drawn.

Right click to end the current Line sequence, and right click again to end the Line command.



The part drawing should now look like this.



Start the Circle command to draw circles which will become the arcs at each end of the slot.

coordinate			
	World :	On plane :	
X-Coord	0	0	
Y-Coord	0	0	
Z-Coord	0	0	
	🗹 ok	+ Inc	
parameters	Diameter	10]	Type 10 in the Diameter entry box.



Click on the lower endpoint of the centerline to draw the first end arc of the slot.

	Diamete	er <mark>20]</mark>	Type 20 in the Diameter entry box
parameters			
	🗹 ok	+ Inc	
Z-Coord	0	0	
Y-Coord	35	35	
X-Coord	35	35	
	World :	On plane :	
coordinate			



Click on the upper endpoint of the centerline to draw the second end arc of the slot.





Right click to end the Arc command. You should now have two circles of unequal diameter, one at each end of the centerline.

Next we will join the circles with tangent lines.



Start the Line Tangent command in the Line menu of the Toolbox.





Draw the first tangent line by clicking near where the tangents will be.





Draw the second tangent line by clicking near where the tangents will be.



Right click to end the Line Tangent command and you will have two tangential lines as shown here.



Begin the Single Selection command.



Select the 45 degree centerline.

Right click to end the selection process.



Click the Delete icon or press the Delete key to delete the centerline.



All we have to do now is trim the circles to the tangent lines to finish the slot.



Start the Scissors command on the Trim menu.



Click on the unwanted segment of the lower circle to trim it away. Circles have an endpoint at 0° so you must click twice to remove both ends of it.



Click on the unwanted segment of the upper circle to trim it away. The remaining arc will be composed of two arcs because of the circle endpoint at 0° . It is good practice to trim this to one arc. Click below the 0° endpoint to remove the smaller arc.



Because the smaller arc is not crossed by any other entity, the Scissors command removes it completely.



Right click to end the Scissors command.



Start the Trim Two command.



Click on the tangent line to select it as the first entity to trim. Click between the endpoint and the midpoint of the line.



Click on the arc to select it as the second entity to trim.



The two entities will now be joined perfectly.

Your drawing should now look like the picture at the beginning of this tutorial, which is now complete.

OneCNC CAD Tutorial 3 Solid Modeling by Extrusion

This tutorial is intended for Expert and Professional versions of OneCNC.



In this tutorial we will use OneCNC solid extrude commands to construct a 3D solid part. You will need the outlines drawn in CAD Tutorial 2 before attempting this tutorial. We will extrude the part with a taper angle and cut the through slot with vertical walls.

Step 1: Complete CAD Tutorial 2 and save a copy.



Complete 'CAD Tutorial 2' and save the file. Use Save As on the File menu to save a copy as 'CAD Tutorial 3'. Press the Space bar and set the view to Trimetric. Your part should appear as shown in this image.

Step 2: Create a solid by extrusion from curves.



Click on the Extrude icon in the Toolbox to open the Extrude menu.



Click on the Extrude Curves icon.



Enter a Taper Angle of 15 in the parameters section of the Toolbox. This will tilt the walls of the extrusion inwards.

Leave the Linear Corners check box unselected.



OneCNC now seeks a boundary to create an extrusion from. Hover the mouse anywhere near the external boundary and click to select it as the outline of the part. The entire outer boundary will be selected with one click.



You can extrude a shape with one or more openings, so the cursor will continue to seek boundaries.

Do not select the inner boundary.

Right click to end the selection stage of the command because in this case we want to create the slot using different settings.



The height of the extrusion can be set by a mouse click or by entering the height in the toolbox. As you move the mouse, you will see a preview of the extrusion, and the current height will be displayed in the toolbox height entry.

parameters
Linear corners 📃
Taper angle 15
Height 10

Enter a Height of 10 in the parameters section of the Toolbox, and press the Enter key.



Click in the drawing window and the extruded solid is created with an external taper of 15 degrees.



Step 3: Create the slot with an extrude cut

The slot boundary we want to use is obscured by the solid we have made. We could change the view direction but there is no need to do this, as we can change the model display setting to Transparent.



Click on the Display icon to open the Display menu.



Select Transparent. The slot geometry will now be visible through the part.

Click on the Extrude cut icon in the Extrude menu.





Change the Taper Angle to 0 so the slot will have vertical walls.



Select the internal boundary to create the cut extrusion.

Only one boundary can be used for an Extrude cut so you do not have to right click to end the boundary selection.



Because we want a through cut the exact extrusion distance is not important. Move the mouse pointer up until the extrusion preview is above the part, and click to make the extrude cut.





Right click to end the Extrude Cut command.



Click on the Display icon and change the display mode back to Normal.



OneCNC CAD Tutorial 4 Working With Planes

All new line and arc geometry, and surface and solid models, are created in the current construction coordinate system, which is independent of the world coordinate system.

When you open a new file in OneCNC, the current construction plane is the XY plane. The X and Y axes of this plane coincide with the X and Y axes of the world coordinate system.



A transparent rectangle indicates the position and orientation of the XY plane of the current construction coordinate system. The Origin selector at the right of the Status bar shows World coordinate input is active.



Clicking on the Origin selector will activate Plane coordinate input. A plane origin indicator will appear.



As an introduction to Plane functions we will position a Plane as an aid to constructing a truncated wireframe pyramid.

Step 1: Draw a pyramid wireframe

Start a new file, and save it as 'Cad Tutorial 4'.



Select World coordinate input, and use the Rectangle command to draw a square from X0 Y0 to X100 Y100.



Start the Line command, and click on the corner of the square to start the first edge of the pyramid.

coordinate	
World :	On plane :
X-Coord 50	50
Y-Coord 50	50
Z-Coord 100	100
🗹 ok	+ Inc

Enter World coordinates as shown to end the edge at the vertex of the pyramid.



Click on an adjacent corner of the square to finish the second edge of the pyramid.



Right click to end the current Line sequence, and construct the other two edges by clicking on corner, vertex, and corner. Right click twice to end the Line command.

Step 2: Position the plane



Open the Planes dialog by clicking on the Plane icon in the Status Bar.

Planes Saved Planes : Current plane XY Default Plane XZ Plane XZ Plane	B0 A0 B0 A0 B90 A90 B180 A90	In the Planes dialog you will see the XY Default Plane is selected in the Saved Planes list. You will also see the pre-defined YZ and XZ planes.
Save Delete Rename	X Close	The Display active plane check box mus be selected for the plane to be visible.



Click on the Push or Pull Plane icon in the Planes dialog.

This command will move the current plane up or down along its ${\sf Z}$ axis.



Enter a drag amount of 50, and click OK.

The plane will be moved vertically by 50mm.



plane

Click on the Origin selector to activate plane coordinates. The Plane origin indicator shows the origin of the moved plane.

We will now tilt the plane on its own Y axis to create the angle for truncation of the pyramid



Click on the Plane icon again to open the Planes dialog.



Click on the Rotate Plane icon.

Rotation Amounts	×
	× Rotation : 0
	Y Rotation : 0
	Z Rotation : 0
	Plane X Tilt : 0
	Plane Y Tilt : 15
	Plane Z Tilt : 0
F8 - Calculator	🗸 OK 🗙 Cancel

The plane can be rotated around the World axes or its own axes.

To rotate the plane around its own Y axis, enter 15 in the Plane Y tilt entry box and click OK.



The plane is tilted on its own Y axis. The plane origin will still be directly above the World origin.

We will save this plane position so we can return to it easily.

Step 3: Save the plane position

Click on the Plane icon again to open the Planes dialog.



plane name		×
Truncation plane		
	🖌 ОК	🗙 Cancel

Name the plane Truncation plane and click OK.



Step 4: Create the truncated pyramid



To truncate the pyramid edges, open the Trim menu in the Toolbox, and click on the Trim to plane icon. This command trims lines or arcs which pass through the plane to the plane intersection.



Click on an edge of the pyramid, between the base and the plane.

The edge will be cut off where it meets the plane. Click on the next edge to trim it.



The edge will be cut off where it meets the plane. Click on the next edge to trim it.



Continue until all four lines are trimmed to the plane.

When you have trimmed all four side edges of the pyramid, use the



Line command to join them. These lines form the boundary of the truncation.

Step 5: Return to default XY plane



To return to the XY plane, open the Planes dialog and select the XY plane in the Saved Planes List.

To return to World coordinate input, clear the Use plane coordinate system check box before clicking OK.



You will see the XY plane is current again.



You can return to the truncation plane by selecting it in the Saved Planes list.

To learn more about plane commands in OneCNC, go to 'Construction Planes' in the CAD section of OneCNC Help.

OneCNC Technical Drawing Automated 3D to 2D Drawing Layouts

This tutorial is intended for Expert versions of OneCNC, and Solid Creator.

Automated 3D model to 2D CAD drawing is a standard feature of OneCNC Solid Creator and OneCNC Expert versions, and can be added as an optional module to OneCNC Mill Professional.



Traditionally, a technical drawing was the first step in production of a part. Now, you can design the part as a 3D model, and create one or more technical drawings automatically from the part.

The paperspace drawings are associated to the model, so if the design changes, you can change the part model and then update the drawing views automatically to show the revised part.

There are two stages to creating a technical drawing in OneCNC. The first step is to create a drawing page layout with title block and border. You can then create and manage views of your model in the layout.

Add a drawing page with border and title block



To add a new page, click on the Pages icon in the Status Bar.

The Page Manager dialog will open.

Page Manager		×	
Pages:			
Model Space	Add page		
	Edit page	115	Click on the Add page
	Delete page		icon to open the Page
	Update page		Setup dialog.
Viewic •			
Model Space View	Place view on page	2	
1 : Front View	Create section from plane		
2 : Top View			
4 : Right View	Create view from pla	ne	
Default View	Create section dimen	sion	
Isometric View	Delete view		
Dimetric View			
Bottom View			
Back View			
_			
Preview of view :			
	^		
^			
	•/		
	•		
Preferences		🗸 ок	
There encount			

ine or page :	Template preview :	
rototype MkI A2		
Templates D:\OneCNC-XR8\Mil 3D Expert\templates\ DIN A4.ONECNC		
Guobiao A1.ONECNC Guobiao A2.ONECNC		
Guobiao A3.ONECNC	L.	-
ISO A0. ONECNC		
ISO A1.ONECNC	H	
ISO A2.ONECNC ISO A3.ONECNC		
ISO A4.ONECNC	H	
JIS A0.ONECNC		P III D I IVANAN
JIS ALONECINC	H	
Custom size		
) Custom size	Auto fill template :	
Custom size Width : 594 Height : 420	Auto fil template : [AUTHOR]	Default
O Custom size Width : \$94 Height : 420	Auto fil template : [AUTHOR] [DATE]	Default July 02, 2020
) Custom size Width : 594 Height : 420	Auto fill template : [AUTHOR] [DATE] [SCALE]	Default July 02, 2200 1:1
Custom size Width : 594 Height : 420 Automatic page ratio	Auto fil template : [AUTHOR] [DATE] [SCALE] [TITLE]	Default July 02, 2020 1 : 1 mill express pocket
Custom size Width : 594 Height : 420	Auto fil template : [AUTHOR] [DATE] [SCALE] [TITLE] [COMPANY]	Default July 02, 2020 1:1 mill express pocket
Custom size Width : 594 Height : 420 Automatic page ratio larger views smaller views	Auto fil template : [AUTHOR] [DATE] [SCALE] [TTTLE] [COMPANY] [FILE_PATH] FOR DEPART	Default July 02, 2020 11:1 mill express pocket Dr.OneCNC-XR8.MMI 3D Expert\Drawings\Samples\mill express poc
Custom size Width : 594 Height : 420 Automatic page rabo larger views smaller views	Auto fil template : [AUTHOR] [DATE] [SCALE] [TITLE] [COMPANY] [FILE_PATH] [FILE_DIRECTORY]	Default July 02, 2020 1:1 mill express pocket Dr.OneCNC-XR8/Mill 3D Expert/Drawings/Samples/mill express poc Dr.OneCNC-XR8/Mill 3D Expert/Drawings/Samples
Custom size Width : 594 Height : 420 Automatic page ratio larger views smaller views Scale - trans : 1	Auto fil template : [AUTHOR] [DATE] [SCALE] [TITLE] [COMPANY] [FILE_PATH] [FILE_PATH] [FILE_PATH] [FILE_PATH] [FILE_PATH]	Default July 02, 2020 1:1 mill express pocket Dr.Onec/NC-XR8/Mill 3D Expert/Drawings/Samples/mill express poc Dr.Onec/NC-XR8/Mill 3D Expert/Drawings/Samples/ 1
Custom size With : 594 Height : 420 Automatic page ratio larger views smaller views Scale - Imm : 1	Auto fil template : [AUTH-OR] [DATE] [SCALE] [TITLE] [COMPANY] [FILE_DATH] [FILE_DATH] [FILE_DATH] [PG6] TEMPLATE]	Default July 02, 2020 1:1 mill express pocket D:\OneCNC-XR8\Mill 3D Expert\Drawings\Samples\mill express poc D:\OneCNC-XR8\Mill 3D Expert\Drawings\Samples 420 1 ISD 42
Custom size Width : 594 Height : 420 Automatic page rabo larger Views smaller Views Scale - Imm : 1	Auto fil template : [AUTHOR] [DATE] [SCALE] [TTTLE] [COMPANY] [FILE, PATH] [FILE, DIRECTORY] [FILE, DIRECTORY] [FILE, DIRECTORY] [FILE, DIRECTORY]	Default July 02, 2020 11:1 mill express pocket Dr:OneCNC-XR8/Mill 3D Expert/Drawings(Samples/mill express poc Dr:OneCNC-XR8/Mill 3D Expert/Drawings(Samples/ 1 1 So A2 OneCNC-XR8 4B Bt Mill 3D Expert - Version 62.77
Custom size Width : 594 Height : 420 Automatic page ratio larger views smaller views Scale - 1mm : 1	Auto fil template : [AUTHOR] [DATE] [SCALE] [COMPANY] [FILE_PATH] [FILE_DIRE_CIORY] [PEGHT] [PGG] [TEMPLATE] [VERSION] WIDTH]	Default July 02, 2020 11:1 mill express pocket Dr\OneCNC-XR8\Mill 3D Expert\Drawings\Samples\mill express poc Dr\OneCNC-XR8\Mill 3D Expert\Unawings\Samples 420 1 ISO A2 OneCNC-XR8 64 Bit Mill 3D Expert - Version 62.77 594
Custom size Width : 594 Height : 420 Automatic page rabo larger views smaller views Scale - 1mm : 1	Auto fil templete : [AUTHOR] [DATE] [SCALE] [TTLE] [COMPANY] [FILE_DRECTORY] [FILE_DRECTORY] [FILE_DRECTORY] [FIESTORY] [VERSION] [VIESTON] [VIESTON]	Default July 02, 2020 11:1 mill express pocket D:OneCNC-XR8/Mill 3D Expert/Drawings/Samples/mill express poc D:OneCNC-XR8/Mill 3D Expert/Drawings/Samples 1 1 150 A2 OneCNC-XR8 46 Bit Mill 3D Expert - Version 62.77 594 Prototype Mikl A2
Custom size Width : 594 Height : 420 Automatic page ratio larger views smaller views Scale - Imm : 1 Include Revision Table	Auto fil template : [AUTHOR] [DATE] [SCALE] [TTLE] [COMPANY] [FILE PATH] [PGE] [TEMPLATE] [VESION] [VESION] [VESION] [VESION] [VESION]	Default July 02, 2020 11:1 mill express pocket Dx\OneCNC-XR8\Mill 3D Expert\Drawings\Samples\mill express poc Dx\OneCNC-XR8\Mill 3D Expert\Urawings\Samples 420 1 ISO A2 OneCNC-XR8 594 Prototype Mkl A2

Templates are supplied for standard paper sizes with pre-drawn borders and title blocks. Select a template for the paper size you want from the Templates list, and enter a name for the page.

The Auto fill template section contains entries which can be automatically added to your title block. Fill these out as necessary, and click OK.

Page Manager	×		
Pages:			
Model Space	Add page		
Prototype MkI A2	Edit page		
	Delete page		
	Update page		

The new page now appears in the Pages list in the Page Manager.

The selected page will be seen in the main drawing window, with the title block showing the details input in the Page Setup dialog. You can now place views from the Views list into the new page.

To return to the main drawing environment, select Model Space in the Pages dialog.

Add views of the model to a drawing page layout

You can add a view of the model to an existing drawing page layout at any stage of the design process.



In the Pages list of the Page Manager, select the page layout you want to add the view to.

Select the view in the Views list, and a preview of the view will appear in the lower section of the Page Manager dialog.

Click the Place view on page icon to add the view to the page.



The view will be attached to the cursor. Click to place the view when it is in the position you want.



After placing the view, you are returned to the Pages Manager again, and you can continue placing views as necessary.

Views are not restricted to orthogonal representations. An Isometric view gives a good indication of what the part actually looks like.



You can create a section view in the Views list using a plane positioned where you want the section.

You can also use a plane to define a view from a specific direction.



Views and section views can be dimensioned as necessary to complete the drawing.

Using the 3D to 2D Technical Drawing module you can quickly create professional drawings to recognized standards. For more detail on using the module see the Automated 3D to 2D drawing topic in the CAD section of OneCNC Help.
OneCNC Support

For assistance contact the OneCNC office for your location.

If you are emailing a support question, it will help us to help you if you zip and attach the file you are having a problem with, and include the following information:

Client Number

Click on Help > About OneCNC. Your client number is a five digit number with the prefix CN. The number is the same as your dongle number.

Version

Click on Help > About OneCNC to find the exact version you are running, e.g. 62.79

OneCNC product The type and level of OneCNC such as Mill Expert.

Units

Please let us know if the file is drawn in metric or imperial units.

OneCNC Global Offices

Australia			
	OneCNC Australia		
	Phone	+61 (0)7 3286 2527	
	Fax	+61 (0)7 3286 4992	
	Email	support@onecnc.com.au	
	Internet	www.onecnc.com.au	
Benelux			
Benefax	OneCNC Benelux		
	Phone	+31 (0) 40 22 66 212	
	Fax	+31 (0) 40 22 40 794	
	Email	support@onecnc.nl	
	Internet	www.onecnc.nl	
Donmark			
Dermark	OneCNC Denmark		
	Phone	+ 45 20 40 02 68	
	Fax	+ 45 20 40 02 68	
	Email	support@onecnc.dk	
	Internet	www.onecnc.dk	
France			
Trance	OneCNC France		
	Phone	+ 33 (0)4 72 33 38 74	
	Fax	+ 33 (0)4 72 91 42 92	
	Email	support@onecnc.fr	
	Internet	www.onecnc.fr	
Germany			
Germany	OneCNC Germa	זע	
	Phone	+49(0)5261 288940	
	Fax	+49(0)5261 2889449	
	Email	support@onecnc.de	
	Internet	www.onecnc.de	
India			
inala	OneCNC India		
	Phone	+61 7 3286 2527	
	Email	support@onecnc.com.au	
	Internet	www.onecnc.in	
Indonesia			
indonesia	OneCNC Indone	sia	
	Phone	+62 31 8411187	
	Email	support@onecnc.id	
	Internet	www.onecnc.co.id	

ireiand

OneCNC Ireland

Phone	+353 7196 33200
Fax	+353 7196 33500
Email	support@onecnc.co.uk
Internet	www.onecnc.co.uk

Italy

OneCNC Italy

Phone	+39 393 438 3373
Fax	+39 178 271 6215
Email	support@onecnc.it
Internet	www.onecnc.it

Japan

OneCNC Japan

Phone	+81 (0)72 760 3134
Fax	+81 (0)72 760 3135
Email	onecnc@onecnc.co.jp
Internet	www.onecnc.co.jp

Korea

OneCNC Korea

+ 82 31 695 7250
+ 82 31 695 7253
support@onecnc.kr
www.onecnc.kr

Mexico

OneCNC Mexico

Phone	+52 (55) 85017429
Email	esanchez@onecnc.com.mx
Internet	www.onecnc.com.mx

Portugal

OneCNC Iberia

Phone	+34 936 473 117
Email	josep.soler@1cnc.es
Internet	www.onecnc.es

Poland

OneCNC Poland

Phone	+48(0)22 388 3460
Fax	+48(0)22 388 3461
Email	support@onecnc.pl
Internet	www.onecnc.pl

South Africa		
	OneCNC South Phone Fax Email Internet	Africa +27 31 7014732 +27 31 7014736 sredman@iafrica.com www.onecnc.net
Spain		
	OneCNC Iberia Phone Email Internet	+34 936 473 117 josep.soler@1cnc.es www.onecnc.es
Sweden		
	OneCNC Sweden Phone Fax Email Internet	n +46 (0)35-7777030 +46 (0)35-7777031 support@onecnc.se www.onecnc.se
Taiwan		
	OneCNC Taiwan Phone Fax Email Internet	+ 886 2 26665010 + 886 2 26660917 chou@wvision.asia www.onecnc.com.tw
United Kingdor	n	
Ū	OneCNC UK Phone Fax Email Internet	+44 (0) 190 237 3054 +44 (0) 190 237 5593 support@onecnc.co.uk www.onecnc.co.uk
USA		
	OneCNC LLC Toll Free Phone Fax Email Internet	+1 877 626 1262 +1 813 874 2335 +1 813 874 2919 support@onecnc.com www.onecnc.com
USA California		
	OneCNC West Phone Fax Email Internet	+1 909 931 7811 +1 909 985 6967 support@onecncwest.com www.onecncwest.com

Copyright Notice

Copyright Notice

Copyright © 2020 All Rights Reserved

This publication or parts thereof, may not be reproduced in any form, by any method, for any purpose.

Trademarks

The following are registered trademarks of QARM Pty Ltd, in Australia and/or other countries: OneCNC XR8, OneCNC XR7, OneCNC XR6, OneCNC XR5, OneCNC XR4, OneCNC XR3, OneCNC XR2, OneCNC XR, OneCNC XP, OneCNC 2003, OneCNC 2000, OneCNC, AusWire, AusMill, AusCAD, AusCADCAM, NCSentry, NCLink.

Third-Party Trademarks

All other brand names, product names or trademarks belong to their respective holders.

QARM Pty Ltd. MAKES NO WARRANTY, EITHER EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, REGARDING THESE MATERIALS AND MAKES SUCH MATERIALS AVAILABLE SOLELY ON AN "AS-IS" BASIS. IN NO EVENT SHALL QARM Pty Ltd BE LIABLE TO ANYONE FOR SPECIAL, COLLATERAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES IN CONNECTION WITH OR ARISING OUT OF PURCHASE OR USE OF THESE MATERIALS. THE SOLE AND EXCLUSIVE LIABILITY QARM Pty Ltd., REGARDLESS OF THE FORM OF ACTION, SHALL NOT EXCEED THE PURCHASE PRICE OF THE MATERIALS DESCRIBED HEREIN.

QARM Pty Ltd reserves the right to revise and improve its products as it sees fit. This publication describes the state of this product at the time of its publication, and may not reflect the product at all times in the future.



Introduction to OneCNC Solid Design v62.80